

Building Acoustics  
Single-Leaf Walls

03



### 3 Airborne Sound Insulation of Single-Leaf Constructions

by L. Nederlof, J.J.M. Cauberg, L. Nijs and M.J. Tenpierik

#### 3.1 Introduction

It is quite common in practice to consider the airborne sound insulation as a construction property which will be or has already been measured, either in a laboratory or in a real-life situation. As far as measured data are available and reliable, it is highly recommended to use those. If such data are not available, measurements can still be done. In fact, sometimes you are obliged to do measurements.

However, measurements are costly and time-consuming which immediately raises the questions whether we can do without them. Besides, designing using an ever extending catalogue with typical constructions does not really seem smart. What we thus need is a physical model that predicts the sound insulation of a construction and shows the relationships between sound insulation, material, size and layout. Using such a model enables us to on the one hand predict the airborne sound insulation in advance and on the other hand design constructions more efficiently. In this chapter such a physical model for single-leaf constructions or in other words homogeneous constructions will be discussed.

#### 3.2 Mass law for single-leaf walls

##### 3.2.1 Theoretical mass law for normal incidence

The sound insulation of a single-leaf wall can be theoretically predicted by a so-called mass law. Figure 3.1 schematically presents the acoustic model for airborne sound transmission through a homogeneous wall for normal incidence of sound waves. Coincidence effects, which will be discussed later in this chapter, can then thus be neglected. This model is a simplified version of reality since we assume that the wall has infinite dimensions in length and width. Besides, we assume that the wall consists of just one layer and is infinitely stiff so that no bending takes place (piston model). Moreover, we first assume normal incidence of sound waves. These simplifications allow a one-dimensional representation of the problem (Figure 3.1).

When a sound wave reflects against a flat infinitely stiff construction, the following mathematical relationship between the velocity of the acoustic waves and their respective pressures applies:

$$v_t = \frac{\partial u}{\partial t} = v_i - v_r \quad \Leftrightarrow \quad p_t = \rho_{\text{air}} c_{\text{air}} \frac{\partial u}{\partial t} = p_i - p_r \quad (3.1a),$$

with

- $v_i$  = the vibration speed of air molecules of the incident sound wave [m/s]
- $v_r$  = the vibration speed of air molecules of the reflected sound wave [m/s]
- $v_t$  = the vibration speed of air molecules of the transmitted sound wave [m/s]
- $p_i$  = the pressure of the incident sound wave [Pa]
- $p_r$  = the pressure of the reflected sound wave [Pa]
- $p_t$  = the pressure of the transmitted sound wave [Pa]
- $u$  = the displacement of the wall [m]
- $\rho_{\text{air}} c_{\text{air}}$  = the specific acoustic impedance of a plane progressive wave (=410 kg/(m<sup>2</sup>·s)).

On the incident side of the wall, the total sound pressure equals

$$p = p_i + p_r \quad \Leftrightarrow \quad p + p_t = 2p_i \quad (3.1b).$$




Figure 3.1 – Physical model for a single-leaf wall for normally incident acoustic waves.

Due to a pressure difference the wall starts to oscillate. According to Newton's second law of motion the movement of the plate should then comply with

$$p - p_t = m \frac{\partial^2 u}{\partial t^2} \quad \Leftrightarrow \quad p - p_t = m \frac{\partial v_t}{\partial t} \quad (3.1c),$$

with

$m$  = the mass of the wall per square meter [ $\text{kg}/\text{m}^2$ ].

Combining equations (3.1a), (3.1b) and (3.1c) now yields the following differential equation

$$p_i = p_t + \frac{m}{2\rho_{\text{air}} c_{\text{air}}} \frac{\partial p_t}{\partial t} \quad (3.2).$$

The general solution to this type of differential equation is such that, if  $p_i$  is sinusoidal,  $p_t$  is sinusoidal as well and vice versa. If we now insert  $p_t = p_{t,\text{max}} \sin(\omega t)$  in equation (3.2), we immediately see that this is indeed true:

$$p_i = p_{t,\text{max}} \sin(\omega t) + \frac{\omega m}{2\rho_{\text{air}} c_{\text{air}}} p_{t,\text{max}} \cos(\omega t) = p_{t,\text{max}} \sqrt{1 + \left(\frac{\omega m}{2\rho_{\text{air}} c_{\text{air}}}\right)^2} \cdot \sin\left[\omega t + \arctan\left(\frac{\omega m}{2\rho_{\text{air}} c_{\text{air}}}\right)\right] \quad (3.3),$$

with

$\omega$  = the angular frequency of the sound wave ( $\omega = 2\pi f$ ) [ $\text{rad}/\text{s}$ ]

$f$  = the frequency of the sound wave [ $\text{Hz}$ ].

From equation (3.3) we directly observe that indeed  $p_i$  is sinusoidal. The second term of the last sine-term is the argument of the complex function and gives the phase shift of the transmitted acoustic wave relative to the incident sound wave. The square root term is the modulus of the complex function which is equal to the ratio of amplitudes of the incident sound wave to the transmitted sound wave

$$\frac{p_{i,\text{max}}}{p_{t,\text{max}}} = \sqrt{1 + \left(\frac{\omega m}{2\rho_{\text{air}} c_{\text{air}}}\right)^2} \quad (3.4).$$




Figure 3.2 – Physical model for a single-leaf wall for obliquely incident acoustic waves.

Sound intensity is directly proportional to the effective sound pressure squared and thus also with the amplitude squared of the effective sound pressure since  $p_{eff} = p_{max} / \sqrt{2}$  for a sinusoidal sound wave. Using the definition of sound insulation, i.e.  $R = 10 \log(1/t) = 10 \log(I_i/I_t) = 10 \log(|p_i|^2/|p_t|^2)$ , we can now write for the airborne sound insulation of a single-leaf homogeneous wall for normal incidence of sound waves

$$R_{single,L} = 10 \log \left[ 1 + \left( \frac{\omega m}{2 \rho_{air} c_{air}} \right)^2 \right] \quad (3.5).$$

### 3.2.2 Theoretical mass law for oblique incidence

Oblique incidence of sound waves can be treated in a similar way as normal incidence by using the components of  $v_i$ ,  $v_r$  and  $v_t$  along the normal of the construction in equations (3.1a) to (3.1c), i.e. by multiplying the velocities with  $\cos \theta$ . This is shown in Figure 3.2. Equation (3.5a) then changes to

$$R_{single,\theta} = 10 \log \left[ 1 + \left( \frac{\omega m \cos \theta}{2 \rho_{air} c_{air}} \right)^2 \right] \quad \text{theoretical mass law} \quad (3.6a).$$

If  $\omega m / 2 \rho_{air} c_{air} \gg 1$ , or in other words if  $f m \gg \rho_{air} c_{air} / \pi = 130 \text{ kg}/(\text{m}^2\text{s})$ , this equation can be simplified. Since in general we work with frequencies higher than 63 Hz, this condition is satisfied if  $m \gg 2 \text{ kg}/\text{m}^2$  which almost always is the case in practice except when thin foils or membranes are used. The simplified equation then becomes

$$R_{single,\theta} \approx 20 \log \left( \frac{\omega m \cos \theta}{2 \rho_{air} c_{air}} \right) \approx 20 \log \left( \frac{f m \cos \theta}{500} \right) + 12 \quad \text{theoretical mass law} \quad (3.6b).$$

These equations clearly demonstrate that according to the mass law the airborne sound insulation of a single-leaf wall increases with  $20 \log \omega = 6 \text{ dB}$  per octave (=6 dB per doubling of frequency) but also with 6 dB per doubling of mass; and that the highest sound insulation is found for normal incidence. So, the bigger the angle  $\theta$  is, the worse the airborne sound insulation is. A practical consequence of this phenomenon can be observed in high-rise buildings where people on the highest floors sometimes experience more nuisance than on the lower floors.

### 3.2.3 Theoretical mass law for random incidence

In practice, however, especially inside buildings, the sound field is diffuse. As a consequence, acoustic waves hitting the cavity construction have multiple directions. We assume that all directions, thus all angles of incidence, are equally and simultaneously present in the sound field in front of the construction. We call this type of incidence random incidence or uniformly distributed incidence. To obtain the airborne sound insulation for such random incidence, we must average equation (3.6b) over all angles of incidence<sup>1</sup> within half a unit sphere. This is done as follows:

$$10\log\left[\frac{1}{2\pi}\int_0^{\pi/2}\cos^2\theta d\Omega\right]=10\log\left[\frac{1}{2\pi}\int_0^{\pi/2}2\pi\sin\theta\cos^2\theta d\theta\right]\approx 5 \quad (3.7).$$

The airborne sound insulation of a single leaf wall for random incidence thus equals its airborne sound insulation for normal incidence minus approximately 5 dB.

$$R_{\text{single;random}} \approx R_{\text{single;l}} - 5 \quad (3.8).$$

### 3.2.4 Empirical mass laws for random incidence

The theoretical mass law predicts an increase of 6 dB/oct. In practice however this increase is mostly limited to about 5 dB/oct. Moreover, contrary to theoretical predictions the insulation curve is mostly not smooth and the sound insulation values are generally somewhat lower than according to theoretical predictions. Because of these issues so-called empirical mass laws have been developed as well. As the theoretical mass law, empirical mass laws assume infinitely stiff walls. They were however derived from measurements in a laboratory. One such empirical mass law for random incidence is

$$R_{\text{single;random}} = 17.5\log(m) + 17.5\log\left(\frac{f}{500}\right) + 3 \quad \text{empirical mass law} \quad (3.9a).$$

Some other empirical mass laws exist to predict the sound insulation at 500 Hz. To get the values at different frequencies 4 to 5 dB needs to be added (towards higher frequencies) or subtracted (towards lower frequencies). They are given as

$$R_{\text{single;random;500}} = 13.3\log(10m) \quad \text{for } m < 200 \text{ kg/m}^2 \quad \text{empirical mass law} \quad (3.9b),$$

$$R_{\text{single;random;500}} = 15\log(4m) \quad \text{for } m > 200 \text{ kg/m}^2 \quad \text{empirical mass law} \quad (3.9c),$$

$$R_{\text{single;random;500}} = 12 + 5.3\sqrt[3]{m} \quad \text{empirical mass law} \quad (3.9d).$$

### 3.2.5 General frequency-dependent behaviour

Some anomalies in the sound insulation curves can however not be explained by both the theoretical and the empirical mass laws. For the derivation of these laws several assumptions were made. One of those was that the wall or plate had infinite stiffness. This implies that no bending phenomena can occur and that the behaviour of the plate in in-plane direction is totally neglected. In reality however such bending phenomena do occur and they can decrease the airborne sound insulation profoundly. Two such phenomena exist: plate resonances at very low frequencies and coincidence (at higher frequencies). These phenomena will be discussed in the next sections.

---

<sup>1</sup> In existing literature not all angles of incidence are taken; mostly only from 0° to some angle between 80° and 90°. Angles of incidence larger than 80° hardly ever occur.




Figure 3.3 – General frequency-dependent behaviour of single-leaf wall.

The general frequency-dependent behaviour of the sound insulation of a single-leaf wall including bending phenomena can now be depicted. Figure 3.3 shows this general behaviour. As can be seen, at very low frequencies plate resonances dominate the acoustic behaviour of a single-leaf wall. As will be discussed in the next section such plate resonances are hardly ever observable in practice. Above these resonances, mass law behaviour theoretically predicts an increase of 6 dB/oct. represented by a straight line in the figure. Around or above a certain frequency, called the coincidence frequency, coincidence reduces the sound insulation considerably.

### 3.3 Plate resonances at very low frequencies

The model presented in the previous sections assumed an infinitely stiff plate which moves frictionless. Such a model does not entirely represent reality since walls and floors are attached to other parts of the building. As a result their movement especially near their edges is restricted. A sound wave hitting a wall or a floor thus causes transversal bending waves inside this wall or floor. The amplitude of these waves depends among others on material, size, thickness and edge conditions. At certain frequencies plate resonances occur which influence the airborne sound insulation.

In general bending waves thus lead to a lower airborne sound insulation. The sound that is radiated from a vibrating plate to a room can be represented by a so-called radiation factor  $\sigma$  which reflects the efficiency with which vibration energy is given off from a construction element to air. The radiation factor of a plate that vibrates in bending thus is less than one. The radiation factor is defined as the ratio of the sound power given off by a plate and the sound power that would be given off by an equally large infinitely stiff plate that moves frictionless with the same average vibration speed:

$$\sigma = \frac{W}{\rho_{air} c_{air} \bar{v}^2 S} \quad (3.10),$$

With

- $W$  = the radiated sound power of a plate or wall [W]
- $\bar{v}$  = the average vibration speed of the plate or wall [m/s]
- $S$  = the surface area of the wall [m<sup>2</sup>].

Since the range of the vibration factor is very wide, in practice mostly a logarithmic scale is used. In figures that represent this radiation factor therefore most often  $10 \log \sigma$  in stead of just  $\sigma$  is found along the vertical axis.




Figure 3.4 – Plate resonances with modes 1,1; 1,2, 2,1; and 2,2 (Martin, 2007).

Plate resonances inside a single-leaf plate are thus caused by bending waves inside this plate. In fact they are transversal standing waves inside the plate, similar to the standing waves of a piano string. They occur in the direction of the length and the width of the plate but also in form of two-dimensional resonances. As shown in Figure 3.4. The frequencies where such standing waves occur depend among other on the edge conditions of the plate. Several edge conditions can be distinguished:

- rigidly connected edges → no displacement and rotation possible
- hinged or pinned connection → no displacement possible; rotation allowed
- free connection → both displacement and rotation allowed.

In practice most connections can in some way or another be schematised with sufficient accuracy as hinged or pinned connections. For this type of edge connection, the resonance frequencies,  $f_{n,m}$  [Hz], for standing waves inside a plate can be calculated from

$$f_{n,m} = \frac{\pi}{2} \sqrt{\frac{B}{\rho_p d_p}} \left[ \left( \frac{n}{l} \right)^2 + \left( \frac{m}{b} \right)^2 \right] \quad (3.11),$$

with

- $n, m$  = an integer representing the mode of vibration ( $n=1, 2, 3, \dots; m=1, 2, 3, \dots$ )
- $\rho_p$  = the density or specific mass of the plate, wall or floor [ $\text{kg}/\text{m}^3$ ]
- $d_p$  = the thickness of the plate, wall or floor [m]
- $l$  = the length of the plate, wall or floor [m]
- $b$  = the width of the plate, wall or floor [m]
- $B$  = the bending stiffness of the plate, wall or floor per meter [Nm].

Structural mechanics tells us that for a single-leaf homogeneous plate the bending stiffness  $B$  equals

$$B = \frac{E d_p^3}{12} \quad (3.12),$$

with

- $E$  = the materials Young's modulus or modulus of elasticity [ $\text{N}/\text{m}^2$ ].

Combining equations (3.11) and (3.12) yields

$$f_{n,m} = \frac{\pi}{2\sqrt{12}} d_p \sqrt{\frac{E}{\rho_p}} \left[ \left( \frac{n}{l} \right)^2 + \left( \frac{m}{b} \right)^2 \right] \approx 0.45 d_p c_L \left[ \left( \frac{n}{l} \right)^2 + \left( \frac{m}{b} \right)^2 \right] \quad (3.13),$$

with

- $c_L$  = the speed of a longitudinal wave through a material similar to  $c_{\text{air}}$  for air ( $c_L = \sqrt{E/\rho_p}$ ) [m/s]

This equation shows us that the resonance frequencies indeed depend on thickness, size and material.



n→ m↓	0	1	2	3
0		6	26	58
1	18	24	43	75
2	71	77	97	129
3	160	166	186	218

Table 3.1 – Frequencies where plate resonances occur inside a glass sheet of 1.5x0.9 m<sup>2</sup> with a thickness of 6 mm.

Table 3.1 presents some values of the resonance frequencies of a 6 mm thick glass sheet. Plate resonances however in practice hardly ever cause problems. First, the lowest frequencies where plate resonances occur are quite low, i.e. far below the frequencies which are generally considered relevant in architectural acoustics (63 Hz – 4 kHz). Below these lowest resonance frequencies the acoustic behaviour of the plate is determined by its bending stiffness. In that very low frequency region, the mass law is no longer applicable. But as already stated this frequency region is very low and therefore not relevant to architectural practice while at the same time the wavelengths needed to cause the plate to vibrate are very large. In practice therefore hardly ever problems arise from low frequency plate resonances. They can however be observed when a heavy lorry or bus is passing a wall with glazed windows. Second, the higher resonance frequencies ( $n>1$ ;  $m>1$ ) in practice also hardly ever cause problems. They are easily weakened by internal dampening and edge dampening, since high frequencies are more effectively dampened than low frequencies. Only in case of thin non-dampened plates used around vibrating machines plate resonances need special attention. Here, increasing the amount of dampening resolves the problems.

### 3.4 Coincidence

As already explained the mass law cannot entirely explain the complete acoustic behaviour of homogenous constructions. Two phenomena related to the bending of the construction element are not explained by this law. The phenomenon of plate resonances at low frequencies was explained in the previous section. The phenomenon of coincidence will be treated in this section.

The term coincidence is used to describe the acoustic behaviour of a homogeneous wall under influence of oblique and random incidence of sound waves for the situation that two bending waves inside the material run together, or, in other words, coincide. These two waves are a free transversal bending wave and a forced transversal bending wave inside the single-leaf wall.

Figure 3.5 shows in a magnified way how the surface of a plate is deformed by the consecutive wave fronts of an incident plane progressive wave with a certain angle of incidence. Because of the progressive character of the incident sound wave a transversal bending wave is forced onto the plate having a speed equal to  $c_{surf}$ .

If we now look at a fixed point on the surface of the wall, it looks as if at that point the plate is excited by a point load. From such a point free transversal bending waves in the plate will start propagating. These same bending waves emerge when a plate is hit by for instance by a hammer. A typical example from practice are the bending waves that occur in a floor resulting from a person walking on heels. But also a sound wave might cause such free transversal bending waves.




Figure 3.5 – The generation of a forced transversal bending wave in a plate by a plane progressive sound wave.

These free bending waves move with a certain speed through the material depending on the mass of the plate or wall, its dynamic stiffness and the frequency. This speed is described by

$$c_B = \sqrt[4]{\frac{\omega^2 B}{m}} = \sqrt[4]{\frac{E d_p^3}{12m}} \sqrt{2\pi f} \quad (3.14),$$

with

- $B$  = the bending stiffness per meter of the plate [ $\text{Nm}^2/\text{m}$ ] described by equation (3.12)
- $m$  = the plate's mass per square meter [ $\text{kg}/\text{m}^2$ ]
- $\omega$  = the angular frequency ( $=2\pi f$ ) [ $\text{rad}/\text{s}$ ].

A propagation speed like this only occurs in very thin plates. The theory used to derive this equation is therefore called the thin-plate-theory. In plates or walls thicker than a quarter wavelength, bending and shear simultaneously occur, as a result changing the propagation speed of the forced wave inside the material.

In the wall or plate thus two types of bending waves simultaneously occur, each having its own speed: a free and a forced bending wave. Coincidence now occurs when both waves progress with the same speed through the material and their resulting deformations run together. In that situation both waves coincide and amplify their amplitudes. As a result, a drastic decrease in airborne sound insulation value of the wall construction is to be expected. This was already shown in Figure 3.3.

Mathematically speaking, coincidence thus occurs if

$$c_B = c_{surf} = \frac{c_{air}}{\sin \theta} \quad (3.15),$$

with

- $\theta$  = the angle of incidence of the sound wave [ $^\circ$ ]

Equation (3.15) can be re-written in such a way that the frequency where coincidence occurs can be determined. The coincidence frequency can thus be calculated from

$$f_{c;\theta} = \frac{c_{air}^2}{2\pi \sin^2 \theta} \sqrt{\frac{m}{B}} = \frac{c_{air}^2 \sqrt{12}}{2\pi} \frac{1}{d_p \sqrt{E/\rho_p} \sin^2 \theta} \quad (3.16a),$$

which approximately equals

$$f_{c;\theta} \approx \frac{64000}{d_p c_L \sin^2 \theta} \quad (3.16b),$$

with

$\rho_p$  = the density or specific mass of the plate, wall or floor [ $\text{kg}/\text{m}^3$ ]

$d_p$  = the thickness of the plate, wall or floor [m]

$E$  = the plate's dynamic Young's modulus [ $\text{N}/\text{m}^2$ ]

$c_L$  = the speed of a longitudinal wave through a material ( $c_L = \sqrt{E/\rho_p}$ ) [m/s].

This equation clearly shows us that no coincidence occurs for normal incidence of sound waves.

*This equation clearly demonstrates that no coincidence occurs for normal incidence of sound waves since  $\theta=0^\circ$  and as a result  $\sin \theta=0$ . Moreover the lowest frequency where coincidence occurs is for  $90^\circ$  incidence of sound waves, i.e. sound waves propagate in the same direction as the wall or plate. This lowest frequency is called the threshold frequency for coincidence,  $f_{c;th}$ . Below this frequency coincidence cannot occur as well. It is however important to realise that this coincidence restriction represents a limit situation, as a result of which some effect of coincidence can already be found below this threshold.*

This threshold frequency can easily be found from equation (3.16) by inserting  $90^\circ$  for  $\theta$ . The threshold frequency is therefore found where

$$f_{c;th} \approx \frac{64000}{d_p c_L} \quad (3.17).$$

For each material thus the product  $f_{c;th} \cdot d_p$  is constant. Table 3.2 presents the threshold frequency of several examples of homogeneous walls. As can be seen, thickness, density, and dynamic Young's modulus determine this frequency. Particularly thick heavy-weight construction walls might cause problems in practice since their threshold frequency for coincidence is in the range relevant for speech or traffic noise.

The extent to which coincidence however influences the airborne sound insulation of a homogeneous wall depends on the ability of the wall to convert the energy in the bending waves to heat, or in other words its ability to dampen bending waves. This ability is expressed by a loss factor for bending waves,  $\eta$ . For each frequency, this loss factor can be determined from the measured structural reverberation time of the construction,  $T_s$ , according to

$$\eta = \frac{2.2 \cdot T_s}{f} \quad (3.18).$$

In this loss factor all dampening mechanisms are included:

- dampening of the bending waves in the material itself (friction losses);
- (rigid) connections along the wall's edges (edge losses);
- Sound radiation towards the surrounding air (impedance losses).

	$d_p$ [mm]	$\rho_p$ [kg/m <sup>3</sup> ]	$E$ [N/m <sup>2</sup> ]	$f_{c,th}$ [Hz]
steel plate	3.5	7800	$210 \cdot 10^9$	3500
wood chip board	36	650	$3 \cdot 10^9$	800
float glass	6	2500	$70 \cdot 10^9$	2000
concrete	100	2000	$20 \cdot 10^9$	200

Table 3.2 – Threshold frequency (rounded) of several examples of homogeneous walls or plates.

material	$\eta$ [-]	material	$\eta$ [-]
steel	$1 \cdot 10^{-4} - 3 \cdot 10^{-4}$	concrete	$4 \cdot 10^{-3} - 8 \cdot 10^{-3}$
aluminium	$1 \cdot 10^{-4}$	gypsum	$6 \cdot 10^{-3}$
iron	$2 \cdot 10^{-4} - 6 \cdot 10^{-4}$	cellular concrete	$1 \cdot 10^{-2}$
copper	$2 \cdot 10^{-3}$	brick	$1 \cdot 10^{-2} - 2 \cdot 10^{-2}$
lead	$1 \cdot 10^{-2}$	dry sand	$6 \cdot 10^{-2} - 12 \cdot 10^{-2}$
glass	$0.6 \cdot 10^{-3} - 2 \cdot 10^{-3}$	asphalt	$5 \cdot 10^{-2} - 4 \cdot 10^{-1}$
spruce	$0.8 \cdot 10^{-2}$	filth	$0.6 \cdot 10^{-1}$
oak wood	$1 \cdot 10^{-2}$	fibrous blankets	$1 \cdot 10^{-1}$
plywood	$1.3 \cdot 10^{-2}$	cork	$1.3 \cdot 10^{-1} - 1.7 \cdot 10^{-1}$

Table 3.3 – Some values of the loss factor of various materials (or actually constructions) (martin, 2007).

Because the loss factor includes all aforementioned losses, it is no material constant but a property of the entire wall construction including its connections and construction flaws. For a specific type of construction, an averaged value might be used for calculations. A measured curve however will irrevocably reflect a large standard deviation in the results. As can be seen from table 3.3 the value of the loss factor  $\eta$  is around one or two percent.

With this loss factor now the airborne sound insulation of a homogeneous wall near the coincidence frequency can be determined from

$$R_{\text{single},c} = 10 \log \left[ 1 + \left( \frac{\omega_{c,\theta} m \cos \theta}{2 \rho_{\text{air}} c_{\text{air}}} \eta \right)^2 \right] \quad (3.19),$$

with

$\omega_{c,\theta}$  = the angular coincidence frequency ( $\omega_{c,\theta} = 2\pi f_{c,\theta}$ ) [rad/s].

Compared to the original theoretical mass law, the airborne sound insulation near coincidence thus drops with about  $20 \log \eta$ . If no dampening losses are present, i.e. if  $\eta = 0$ , the sound insulation even drops to 0 dB.




Figure 3.6 – Coincidence effect for 6 mm float glass for several angles of incidence ( $\eta=0.01$ ).




Figure 3.7 – Coincidence effect for 100 mm concrete for several angles of incidence ( $\eta=0.04$ ).

Figures 3.6 present the theoretical sound insulation curves of 6 mm float glass with infinite width and length. The dip due to coincidence approximately amounts to about  $20 \log(0.01) = 40$  dB. In case of smaller plates, also edge losses will play a role as a result of which  $\eta$  becomes higher and as a consequence the drop in sound insulation smaller. In figure 3.7 the theoretical sound insulation curve of 100 mm concrete with infinite dimensions is shown. The drop in sound insulation resulting from coincidence now occurs at lower frequencies and falls into the frequency range of traffic noise. Figures 3.6 and 3.7 should however not be misinterpreted: coincidence does not disappear with decreasing angle of incidence; it only shifts towards higher frequencies.

Moreover, one should not let oneself be put off by the fact that the theoretical sound insulation curve for oblique incidence with certain specified angle of incidence even gets higher than the theoretical curve for normal incidence ( $\theta=0^\circ$ ) according to the mass law. In practice this is hardly ever observed. In practice we most of the time have to deal with random incidence of sound waves. Since sound is then coming from multiple directions, a wide spectrum of coincidence frequencies and consequently coincidence dips in sound insulation can be found in the insulation curve. The measured sound insulation curve reflects the resulting effect of all these coincidences and is to a large degree determined by the weakest link: the combination of frequency and angle of incidence that meets the coincidence requirement.

*The result is that the sound insulation curve for random incidence first reflects the behaviour of the mass law, then exhibits a plateau and starting from the threshold frequency finally increases with about 7.5 dB/octave. This increase is less rapid than reflected in Figures 3.6 and 3.7 showing 18 dB/octave.*

In the next section first two theoretical models that predict the entire acoustic behaviour of homogeneous walls will be discussed. And in section 3.6 the so-called plateau method will be described that reflects the acoustic behaviour of homogeneous wall constructions for random incidence of sound waves as observed in practice, thus with an increase of 7.5 dB/octave above the threshold frequency.

### 3.5 Advanced theoretical mass law models

More advanced theoretical models exist that predict the entire frequency-dependent airborne sound insulation of homogeneous constructions, thus including coincidence effects. One such model is derived in a similar way as the mass law from section 3.1 but then in a more elaborate form. Nederhof and Cauberg (2005) present the result of this derivation as

$$R_{\text{single};\theta} = 10 \log \left| 1 + i \frac{\omega m \cos \theta}{2 \rho_{\text{air}} c_{\text{air}}} \left( 1 - (1 + i\eta) \frac{\omega^2}{\omega_{c;\theta}^2} \right) \right|^2 \quad (3.20),$$

with:

$i$  = the imaginary unit ( $i^2 = -1$ )

Since this theoretical model results in an increase of sound insulation of 18 dB/octave above the coincidence frequency (Figures 3.6 and 3.7), which does not reflect the increase observed in reality, Häupl (2008) presents a semi-empirical equation that more closely but not entirely resembles the behaviour observed in laboratory measurements. It is written as

$$R_{\text{single};\theta} = 20 \log \left( \frac{\frac{\omega m \cos \theta}{2 \rho_{\text{air}} c_{\text{air}}}}{1 + \sqrt{\left( \frac{\omega_{c;\theta}^2}{\omega^2} - 1 \right)^2 + \left( 2\eta \frac{\omega_{c;\theta}}{\omega} \right)^2}} \right) \quad (3.21).$$

For very high frequencies,  $\omega \gg \omega_{c;\theta}$ , this equation predicts an increase of 6 dB/octave and a sound insulation value 6 dB lower than according to the theoretical mass law (eq. (3.6)).

Figures 3.8 and 3.9 show the theoretical prediction of the airborne sound insulation of a 6 mm glass sheet and 100 mm concrete according to equations (3.20) and (3.21) for 45° incidence. As can be seen clearly, differences between both theoretical equations arise for frequencies higher than the coincidence frequency. Here equation (3.20) predicts a too rapid increase while equation (3.21) predicts a too slow increase. Therefore the so-called plateau method was developed which more accurately predicts the acoustic behaviour of homogeneous walls for random incidence of sound waves in octave bands. This model is explained in the next section.




Figure 3.8 – Theoretical airborne sound insulation of 6 mm float glass at 45° angle of incidence ( $\eta=0.004$ ).




Figure 3.9 – Theoretical airborne sound insulation of 100 mm concrete at 45° angle of incidence ( $\eta=0.007$ ).

### 3.6 Plateau method

As already explained, the general airborne sound insulation of homogeneous walls is:

- below the lowest eigenfrequency of the wall determined by its flexural stiffness;
- in a limited frequency range from the lowest eigenfrequency till somewhat below the threshold frequency for coincidence determined by the inertia of mass resulting in an increase of 5 to 6 dB/octave;
- above the threshold frequency for coincidence possibly determined by coincidence (for oblique and random incidence);
- far above the threshold frequency for coincidence increasing with 7 to 9 dB/octave.

The exact shape of the sound insulation curve is strongly influenced by plate resonances and coincidence. A complete mathematical model that includes all these aspects is very complex. Simplified models have been developed that can easily be used in practice. Although these models are highly stylised and simplified, conscious use allows a good comparison of homogeneous walls among one another. One such simplified model is the 3-step model of plateau model for stony materials. This model predicts the airborne sound insulation of *stony materials for random incidence* rather accurately. It is described below.

In this model the sound insulation curve is stylised as three straight lines: a line representing the mass law (A), a line representing a plateau caused by coincidence (B), and a line representing the sound insulation above the coincidence threshold frequency (C). In Figure 3.10 these lines are shown.




Figure 3.10 – Plateau method for predicting the sound insulation of stony homogeneous walls for random incidence.

The plateau in this figure ends at the threshold frequency for coincidence but starts already near

$$f_1 = f_{c;th} \sqrt{2\eta} \quad (3.22).$$

Based upon this frequency and the threshold frequency for coincidence the three lines can now be determined. In the low frequency region (A), the theoretical mass law for random incidence applies:

$$R_A = R_{\text{single};\perp} - 5 \approx 20 \log \left( \frac{\omega m}{2\rho_{\text{air}} c_{\text{air}}} \right) - 5 \approx 20 \log \left( \frac{f m}{500} \right) + 7 \quad (3.23a);$$

the plateau between the frequencies  $f_1$  and  $f_{c;th}$  (B) can be found by inserting the frequency  $f_1$  for  $f$  in the previous equation

$$R_B = R_{\text{single};\perp}(f_1) - 5 \approx 20 \log \left( \frac{f_1 m}{500} \right) + 7 = 20 \log \left( \frac{f_{c;th} m}{500} \right) + 10 \log(2\eta) + 7 \quad (3.23b);$$

in the high frequency region (C), the sound insulation again rises but now with about 7.5 dB/oct according to:

$$R_C = R_B + 25 \log \left( \frac{f}{f_{c;th}} \right) \quad (3.23c).$$

With increasing mass of the wall construction, the coincidence effect becomes less strong; for heavy walls the threshold frequency drops to below 500 Hz which corresponds to a wavelength in the order of 1 m. As a result, in case of walls with normal dimensions the coincidence effect becomes less important. When using the plateau method, it is therefore allowed for walls with a mass higher than 70 kg/m<sup>2</sup> to increase the plateau with a certain value. The permitted increase equals

$$\Delta R_{\text{plateau}} = 20 \log \left( \frac{m}{70} \right) \quad (3.23d).$$

The new raised plateau, line (B\*) in Figure 3.10, however should remain between the (extrapolated) lines A and C. As a result, the start and end frequency of the plateau slightly shift towards higher frequencies. It is important to realise that the plateau already starts below the threshold frequency although actual coincidence cannot yet occur here. However, bending waves do already have an effect in this region. Moreover, materials with low bending wave attenuation, i.e. low loss factor, exhibit a certain swing around the plateau as shown in Figure 3.11.




Figure 3.11 – Swing around the plateau for stony homogeneous materials with low loss factor.



The entire airborne sound insulation of stony walls for random incidence can now be estimated if knowledge of the frequencies  $f_1$  and  $f_{c;th}$  and the height of the plateau  $R_B$  are known. The schematised sound insulation graph can now easily be found using the following steps:

- 1.) Determine  $f_{c;th}$ ;
- 2.) Determine  $f_1$ ;
- 3.) Determine the height of the plateau  $R_B$  and construct line (B);
- 4.) Draw line (A) starting from  $f_1$  with a slope of 6 dB/octave;
- 5.) Draw line (C) starting from  $f_{c;th}$  with a slope of 7.5 dB/octave;
- 6.) Only if the mass of the wall is higher than 70 kg/m<sup>2</sup>, determine  $\Delta R_{plateau}$  and construct a new horizontal line (B\*)  $\Delta R_{plateau}$  above line (B). This new line (B\*) then replaces line (B).

Although the plateau method is easy to use and gives a sufficiently accurate prediction of the sound insulation, it is important to realise that it has its limitations. These limitations are:

- the influence of low frequency plate resonances is neglected;
- the influence of the dimensions of the plate is neglected;
- the influence of stiffening elements attached to the wall or plate are not considered;
- for thick plates ( $d_p > \lambda/4$ ), non standard bending waves occur which are not considered by the model.

Moreover, a comparison of the plateau method to actual laboratory measurements has shown that:

- in case of lightweight soft plates, especially if the loss factor is low, the sound insulation curve is much more whimsical than predicted by the plateau model;
- in case of heavy plates a plateau hardly occurs but rather an increase of the sound insulation with frequency with a certain slope.

### 3.7 Layered constructions

This text will be completed later.

### 3.8 Stiffened constructions

This text will be completed later.

### 3.9 Practical considerations

→ **Read chapter 12 Applied Sound Insulation from the book 'Building Physics' by A.C. van der Linden.**

This text will be completed later.

### 3.10 Literature

Häupl, P. (2008), *Bauphysik – Klima Wärme Feuchte Schall*, Ernst und Sohn Verlag, Berlin, 547 pages.

Martin, H.J. (2007), *Geluidisolatie*, lecture notes for the course Acoustics 7S510, Eindhoven University of Technology, Eindhoven.

Nederlof, L. and Cauberg, J.J.M. (2005), "Luchtgeluidisolatie – Coincidentie-effect", *Kennisbank Bouwfysica Module A17*, Stichting Kennisoverdracht Bouwfysica.